

Unite

Menü-Struktur und **Werkseinstellungen** | Menu structure and **factory defaults** (TP, RP, RP-T, TH)
Firmware mobile Geräte | Portable devices: V0118 (5. August 2020)

Audio		
Volume	HP Initial Level (Pockets only) Mini XLR Mic (TP) Headset Mic (TP + RP-T) Internal Mic (TP + RP-T) Line in (TP) Sidetone (TP + RP-T)	Mute / -54 dB ... -12 dB ... 12 dB (2 and 3 dB steps) Mute / +0 dB ... 15 dB ... 33 dB (3 dB steps) Mute / +0 dB ... 15 dB ... 33 dB (3 dB steps) Mute / +0 dB ... 15 dB ... 33 dB (3 dB steps) Mute / +0 dB ... 15 dB ... 33 dB (3 dB steps) Mute / -30 dB ... -14 dB ... -2 dB (2 dB steps)
Microphone (TP / TH / RP-T)	Auto / Internal / Mini XLR (TP only) / Headset	
Quality (TP / TH)	HD / SD	
Mute Button (TP / TH)	Push / Toggle	
Line in / Aux (TP)	All / Master / Master + Sub-Masters	
Input Effects	ALC (TP / TH / RP-T)	Off / Near / Far
	Low-Cut Filter (TP / TH / RP-T)	Off / 80 Hz / 120 Hz / 180 Hz / 250 Hz
	Equalizer (TP / TH / RP-T)	Off / Female / Male
	Noise Gate (TP / TH / RP-T)	State: Off / On Threshold: -48dB .. -24dB .. -12dB (3dB steps)
	Noise Canceller (TP / TH / RP-T)	Off / Low / Mid / High
	Compressor (TP / TH / RP-T)	Off / Low / High / Less Pop Noise
	Ducker (TP / TH)	Off / Low / Mid / High

Talkback		
State (TP / TH)	Off / On / Request	
NOM (TP / TH)	One Channel / Two Channels	
Audio Routing (TP / TH)	RP Talkback: All / Master / Master + Sub-Masters Sub-Masters: All / Master / Master + Sub-Masters	
Talk Button (RP-T)	Toggle / Push / Off	

www.beyerdynamic.com

beyerdynamic GmbH & Co. KG
Theresienstraße 8 · 74072 Heilbronn · Germany
Phone +49 7131 617-300 · info@beyerdynamic.de

Weitere Vertriebspartner weltweit finden Sie im Internet unter www.beyerdynamic.com
Abbildungen nicht vertragsbindend. Änderungen vorbehalten.

EN-DE 1 / Unite Menü / (0.2020)

Unite
Systemanleitung



Unite
Landing Page



Unite

Menü-Struktur und **Werkseinstellungen** | Menu structure and **factory defaults** (TP, RP, RP-T, TH)
 Firmware mobile Geräte | Portable devices: V0118 (5. August 2020)

Bluetooth (TP / TH)	
State	Off / Headset / Phone/PC
Connect	
Pair	

System		
Channel Name	Unite	
Group ID	256	1-149 (individual encryption) 150-256 (all IDs share the same factory audio key)
Display	Brightness Dimming Level Dimming Time	10% / 20% .. 100% Off / 10% / 20% ... 50% .. 100% Off / 15 sec / 30 sec / 45 sec / 60 sec .. 240 sec
Auto-Switch-off (RP / RP-T)	Off / On	
Radio Power (TP / TH)	Standard / Mid / Low	
Device Mode (TP / TH)	Master / Sub-Master / AP4 Mic (SubM)	
Button Lock (General Button lock activated on RP + RP-T; deactivated on TP and TH)	Power	Off / On
	Menu	Off / On
	Channel (RP + RP-T) or Function (TP / TH)	Off / On
Reset	Factory Battery	
Information	Battery	Charge, Charging, Avg. Pwr., Temp, To empty
	Device	FW, Build, DECT, Prod. Date, Serial, HW, Bluetooth®

www.beyerdynamic.com

beyerdynamic GmbH & Co. KG
 Theresienstraße 8 · 74072 Heilbronn · Germany
 Phone +49 7131 617-300 · info@beyerdynamic.de

For further distributors worldwide, please go to www.beyerdynamic.com
 Non-contractual illustrations. Subject to change without notice.

Unite
 Operating instructions



Unite
 Landing page

